



UV PRO.LLC

Instruction manual for the device

UV Pro

STEP 1

To start the device, please select the sanitizing mode.
Press and hold the  ON/OFF button to switch between modes.
When desired mode is selected, let go the  ON button.

3 modes:

E - Elite

UV Pro works in intervals to ensure products don't overheat and no damage is done. Use for delicate leathers and fabrics.

- Works 3 minutes on, 3 minutes off. Complete cycle - 12 minutes.


S - Sport

For the Athletes. Hard on your feet? The Sport setting works longer to ensure your shoes stay fresh and clean!

- Complete cycle-20 Minutes
- Not recommended for leather shoes (see Elite).

N - Normal

Our Standard setting is the quickest way to achieve clean. Complete cycle- 10 Minutes.



STEP 2

After mode is selected.

Press the  ON button.

The device will indicate the last selected mode and will start the preselected cycle.

Please note, for your safety the device is equipped with a delayed start. Once you hit the start button, there is a 10 second delay before the device turns on, thus allowing time to move out of range.

After the selected cycle is finished, it will shut down automatically. Comeback to clean and smell free shoes!



Call 877-338-8776
info@myuvpro.com
www.myuvpro.com